

## 6. Cleaning Al-form at site

- a. Immediately clean wet concrete:
  - Using water jet (100~150 bar) to clean the back of form panel right after casting concrete to remove wet concrete stick to the panel
- b. Immediately after dismantling panel:
  - Remove batch of dry concrete on the panel
  - Apply form oil before cleaning with panel which have big batch of dry concrete.
  - Using Scraper only, not allow any heavy tool as hammer, crowbar... to remove.

